



Surfacing Repair

Instructions

WETPOUR & RUBBER MULCH REPAIRS

WHAT'S INCLUDED



WEARING COURSE KIT

Material for a 1m² repair at 20mm thickness
Please note: This is the top layer only



COMPLETE WETPOUR KIT

Material for a 1m² repair at 20mm thickness
plus 1m² of base rubber providing a total
thickness of 40mm**



COMPLETE RUBBER MULCH KIT

Material for a 1m² repair at 20mm thickness
plus 1m² of base rubber providing a total
thickness of 40mm**

*Rubber kits will be pre-measured

**More resin will be supplied than is required for Wetpour Base and Rubber Mulch

TOOLS REQUIRED



- STEEL FLOAT / TROWEL
- STANLEY KNIFE
- PAINT BRUSH
- RUBBER GLOVES (SUPPLIED)
- BUCKET OF SOAPY WATER
- WHEELBARROW / TUB FOR MIXING

MATERIAL MIX RATIOS

WETPOUR

- Base Rubber: 12.5kg of rubber to 1kg resin
- Top Rubber: 12.5kg of rubber to 2.5kg resin

RUBBER MULCH

- 10kg of rubber to 2kg binder
 - Kits are pre-measured
-

STEP 1



Mark out the area to be repaired and use a Stanley Knife to cut out the damaged surface, leaving a neat edge

STEP 2



Removed the damaged surface and any loose material

STEP 3



Use the paint brush to apply some of the resin to the edges of the repair, to aid with the bonding of the new material

STEP 4

 TIP: Ensure you're wearing gloves to mix rubber & binder



Mix the rubber granules and resin binder in the wheelbarrow / mixing tub to the suggested ratio (refer to page 1)

STEP 5



Place the mixed materials into the hole to be repaired

STEP 6



Overfill the area with material to allow for compaction when completing the repair

STEP 7

💡 TIP: Use a spray bottle for your soap and water mixture



Lubricate the Steel Float with Soapy Water and use to level and compact the material into the repair

STEP 8



Clear away any excess material

STEP 9

💡 TIP: We recommend allowing 24 hrs



Leave to cure

VIDEO TUTORIAL

To watch a video tutorial on how to complete your surface repair, please scan the QR code below:



PLEASE NOTE

These instructions are provided as guidance only and do not constitute a comprehensive guide to the laying of Wetpour and Rubber Mulch surface.

We cannot take any responsibility for an incorrectly laid surface.

Do not complete your surfacing repairs in wet weather.

LET'S TALK PLAY!

GET IN TOUCH



FIND OUT MORE ON
OUR WEBSITE



VISIT

www.creativeplayuk.com

Browse our entire product catalogue, view our case studies, read the most up-to-date play industry news AND MORE!



CALL

01244 375627

Talk with our dedicated in-house team to book your design consultation, request a free, no-obligation quotation or talk about the best way to start your playground development.



EMAIL

play@creativeplayuk.com

Leave an email with your playground vision and we'll get back to you ASAP so we can get your project rolling!

STAY SOCIAL



FACEBOOK
[/CreativePlayUK](https://www.facebook.com/CreativePlayUK)



X (FORMERLY KNOWN AS TWITTER)
[@CreativePlayUK](https://twitter.com/CreativePlayUK)



INSTAGRAM
[@CreativePlayUK](https://www.instagram.com/CreativePlayUK)



LINKEDIN
[/creative-play-uk](https://www.linkedin.com/company/creative-play-uk)



YOUTUBE
[@creativeplayukplaygrounds](https://www.youtube.com/channel/UCr3e6p3u3u3u3u3u3u3u3u3)



TIKTOK
[@CreativePlayUK](https://www.tiktok.com/@CreativePlayUK)