




OS123 (4M) - CHALKBOARD

Installation Instructions

**creative
play**




INSIDE SHELTER VIEW



OUTSIDE SHELTER VIEW

PARTS REQUIRED



x1


PRE-ASSEMBLED CHALKBOARD PANEL




x8

97.M8X120CSK

***ENSURE ROOF BRACE TIMBERS (RB) ARE OMITTED DURING SHELTER INSTALL OR REMOVED PRIOR
CHALKBOARD INSTALLATION - SEE BELOW***





BEFORE




AFTER

INSTALLATION INSTRUCTIONS

- 1** **SCREW CHALKBOARD PANEL TO SHELTER USING DIMENSIONS BELOW**
USING M8X120MM WOOD SCREWS, ENSURE IT IS POSITIONED ACCORDING TO DIAGRAMS SHOWN



NOTES:
ENSURE THERE IS AN 81MM GAP LEFT ABOVE AND BELOW CHALKBOARD
4 SCREWS SHOULD BE INSTERTED EVENLY BOTH SIDES



NOTES:
ENSURE CHALKBOARD TIMBER EDGE ON INSIDE OF SHELTER IS FLUSH WITH UPRIGHTS AS SHOWN

CHALKBOARD TIMBER
CHALKBOARD PLAYTEC

