



WO106 - HEARTWOOD


INSTALLATION INSTRUCTIONS

**creative
play**




PARTS REQUIRED

FOR ANY STANDARD JIGSAW PARTS USE THE STANDARD JIGSAW INSTALLATION INSTRUCTIONS.



X6

STANDARD JIGSAW PART
JIGSAW FLOOR ASSEMBLY




X1

inc. standard fixings

STANDARD JIGSAW PART

JIG1515 CLIMBING PANEL WITH BLOCKS -1.5M




X2

inc. standard fixings

STANDARD JIGSAW PART

JIG117 - GUARD RAIL - WINDOW




X7

inc. standard fixings

STANDARD JIGSAW PART

JIG102 - GUARD RAIL - STARIGHT




X1

inc. standard fixings

STANDARD JIGSAW PART

JIG1511 - SLIDE - 1.5M




X1

inc. standard fixings

STANDARD JIGSAW PART

JIG1511(B) - TUBULAR SLIDE - CURVED - 1.5M




X1

inc. standard fixings

STANDARD JIGSAW PART


JIG1513 - RAMP - 1.5M



X2

W0106 - SPECIFIC PART

LARGE WINDOW PANEL




X1

W0106 - SPECIFIC PART


GUARD RAIL

PARTS REQUIRED




X2

W0106 - SPECIFIC PART
MIDDLE PLATFORM FLOOR




X1

W0106 - SPECIFIC PART
MIDDLE BACK PLATFORM FLOOR




X2

W0106 - SPECIFIC PART
W0106-DD



X1

W0106 - SPECIFIC PART
LARGE TIMBER PANEL




X1

W0106 - SPECIFIC PART
NET ASSEMBLY




X1

W0106 - SPECIFIC PART
NET TIMBER ASSEMBLY




X1

W0106 - SPECIFIC PART
ROOF



X1


W0106 - SPECIFIC PART
WOODLANDER TABLE



X2

W0106 - SPECIFIC PART
WOODLANDER SEATS

PARTS REQUIRED




X2

W0106 - SPECIFIC PART
W0106-S




X1

W0106 - SPECIFIC PART
W0106-BB




X2

W0106 - SPECIFIC PART
W0106-CC




X8

W0106 - SPECIFIC PART
EXTENSION PLATES




X4

W0106 - SPECIFIC PART
W0106-II




X2

W0106 - SPECIFIC PART
W0106-HH




X20

W0106 - SPECIFIC PART
W0106-FF



X2







W0106 - SPECIFIC PART
W0106-GG




X1

W0106 - SPECIFIC PART
W0106-RR

PARTS REQUIRED

 <p>X43</p> <p>W0106 - EXTRA FIXINGS</p> <p>COVERED ENDS</p>	 <p>X30</p> <p>W0106 - EXTRA FIXINGS</p> <p>M8X180 SCREWS</p>	 <p>X6</p> <p>inc. standard fixings</p> <p>W0106 - EXTRA FIXINGS</p> <p>POLYFIX HALVES</p>
 <p>X43</p> <p>W0106 - EXTRA FIXINGS</p> <p>M12 NYLOCS</p>	 <p>X128</p> <p>W0106 - EXTRA FIXINGS</p> <p>M8X80 SCREWS</p>	 <p>X28</p> <p>W0106 - EXTRA FIXINGS</p> <p>M12X180 CUP SQUARE BOLTS</p>


TOOLS REQUIRED



INSTALLATION INSTRUCTIONS

ATTACH WO106-GG/ HH AND WO106-II TIMBERS TOGETHER


USING EXTENSION PLATES / 97.M8X80CSK X16




INSTALLATION INSTRUCTIONS

ATTACH STANDARD JIGSAW PLATFORM FLOOR AS PER STANDARD JIGSAW INSTRUCTIONS


PLATFORM 1




PLATFORM 2




PLATFORM 3




PLATFORM 4




PLATFORM 5




PLATFORM 6








SURFACING DETAILS

----- = MINIMUM SPACE
———— = SURFACE AREA





INSTALLATION INSTRUCTIONS

1 INSTALL PLATFORMS AS PER LAYOUT BELOW USING M12X180 [X16], M12 NYLOCS [X16] & END CAPS [X16]




INSTALLATION INSTRUCTIONS

2 INSTALL MIDDLE PLATFORMS AS PER LAYOUT BELOW USING M12X180 [X12], M12 NYLOCS [X12] & END CAPS [X12]





INSTALLATION INSTRUCTIONS

3 INSTALL WO106-BB INTO THE GROUND AS PER GROUND SCREW LAYOUT



4 INSTALL ALL STANDARD JIGSAW PLAY PARTS SHOWN BELOW AS PER STANDARD INSTRUCTIONS - PLEASE NOTE PERVIOUS PRODUCT VISUAL USED BELOW. ROPE HAS BEEN REPLACED WITH PLAYTECH SIDES.

VIEW ONE




VIEW TWO

INSTALLATION INSTRUCTIONS

5

PLEASE NOTE - END CAPS MAY NOT BE REQUIRED
SOME ATTACHEMENT PARTS MEAN END CAPS ARE NOT REQUIRED




NOTES:

TIMBER SUPPORT IS CUT TO FIT AROUND THE NYLOC - CIRCLED ABOVE

6


INSTALL GUARD RAILS AS PER STANDARD INSTUCTIONS AND LOCATIONS SHOWN
USING M8X80 [X8] FOR EACH GUARD RAIL. UNIT SHOULD LOOK LIKE THIS.



INSTALLATION INSTRUCTIONS


7

ATTACH 2X W0106-DD TIMBERS TO LEFT AND RIGHT CENTRAL UPRIGHTS
USING M8X180 SCREWS [X8]



8


INSTALL JIG102 GUARD RAIL TO W0106-DD
USING M8X80 SCREWS [X8]



INSTALLATION INSTRUCTIONS


9

ATTACH 2X JIG117 AS PER STANDARD INSTRUCTIONS IN LOCATIONS SHOWN
USING STANDARD PARTS




10

REMOVE 2X ENDCAPS (CIRCLED ABOVE)




INSTALLATION INSTRUCTIONS

11 ATTACH W0106 SPECIFIC GUARD RAIL. USING M8X80 [X8]




12 FIX W0106 SPECIFIC ROOF TO CENTRAL UPRIGHTS USING STANDARD PARTS




NOTES:
ASSEMBLE AS PER STANDARD INSTALL INSTRUCTIONS (JIG103)

INSTALLATION INSTRUCTIONS

13 MARK ROPE LOCATION ON JIG102 - GUARD RAIL AS SHOWN BELOW.




13a CHECK LOCATION AGAINST ROPE AND DRILL HOLES THROUGH JIG102 - GUARD RAIL




INSTALLATION INSTRUCTIONS

14 **INSTALL W0106-S TIMBER INBETWEEN GUARD RAIL AND PLATFORM FLOOR TIMBER** ENSURE HOLES LINE UP AND CROSS SCREW WITH M8X180 SCREWS [X6]



15 **INSTALL NET TIMBER ASSEMBLY TO UPRIGHTS 1178MM FROM BASE OF GUARD RAIL - USING M8X80 [X8]**




INSTALLATION INSTRUCTIONS

16

ATTACH NET TO PLATFORM FLOORS AND NET TIMBER ASSEMBLY

USING M12 NYLOCS [X15], COVERED ENDS [X15], M8X80* SCREWS [X4] AND M8X180** SCREWS [X4]



NOTES:


* 80 SCREWS - SCREW THROUGH ASSEMBLY (FRONT) INTO PLATFORM FLOOR

** 180 SCREWS - SCREW THROUGH PLATFORM FLOOR TIMBER (BACK) INTO THE NET ASSEMBLY TIMBERS

17


SECURE NET TO UPRIGHTS

USING POLYFIX HALVES [X6]




INSTALLATION INSTRUCTIONS

18 INSTALL WOOLANDER TABLE INTO THE GROUND



19 SCREW WO-TABLE SEATS TO CENTRAL UPRIGHT TIMBERS ON EACH SIDE USING M8X180 SCREWS [X8]. ENSURE FLOOR TO TOP OF SEAT HEIGHT IS 350MM





INSTALLATION INSTRUCTIONS

- 20** **ATTACH LARGE WINDOW PANELS TO BACK LEFT & RIGHT UPRIGHT SECTIONS**
USING M8X80 SCREWS [X6] ON EITHER SIDE OF EACH PANEL (M8X80 X24 IN TOTAL)




- 21** **FIX WO106 SPECIFIC - LARGE TIMBER PANEL TO MIDDLE UPRIGHTS FROM THE INSIDE** USING M8X80 SCREWS [X4] ON EITHER SIDE OF THE PANEL (M8X80 X8 IN TOTAL)



INSTALLATION INSTRUCTIONS

22 SECURE W0106-BB TO GUARD RAIL AND LARGE TIMBER PANEL USING M8X80 [X4] DOWN THE CENTRE OF THE TIMBER



27 ATTACH W0106A-RR TO W0106-FF USING M8X180 [X4]



ADDITIONAL DIMENSIONS

