



OS117 - OCTAVIA CANOPY (4M)

Installation Instructions

**creative
play**



PARTS REQUIRED




UPRIGHT TIMBERS



x228

97.M8X80CSK



x16


97.M8X120CSK



x16

97.M8X180CSK


PARTS REQUIRED



ROOF TRIM / KING 'POST'

RT


QTY x 1 - RT1 - ROOF CAP
QTY x 1 - RT2 - KING POST
QTY x 4 - RT3a - 6x1 TRIM
QTY x 4 - RT3b - 6 x 1 TRIM



ROOF ASSEMBLIES

RA

QTY x 8 - RA - ROOF ASSEMBLIES



ROOF MAIN SUPPORTS

RM

QTY x 8

ROOF SUPPORTS

RS

QTY x 8


ROOF BRACES

RB


QTY x 8 - RB-L (LEFT)
QTY x 8 - RB-R (RIGHT)

FOUNDATION DETAILS

NOTES:
POST HOLES 400MM x 400MM




FOUNDATION DETAILS



INSTALLATION INSTRUCTIONS

1 INSTALL THE UMT TIMBERS ACCORDING TO GROUND PLAN





2 ATTACH THE RS ROOF TIMBERS USING 2 X M8X80MM WOOD SCREW EITHER END, ENSURE TIMBERS ARE POSITIONED AS SHOWN

NOTES:


ENSURE TIMBERS ARE PRE-DRILLED AND COUNTERSUNK

TIMBERS ARE POSITIONED LEVEL WITH THE TOP OF THE UPRIGHT TIMBER





INSTALLATION INSTRUCTIONS



3 ATTACH RM TIMBERS TO KING POST (RT2) AND SCREW TO UPRIGHTS USING 2 X M8X120MM & 2 X M8X180MM WOOD SCREWS



NOTES:
ENSURE SCREWS ARE AS SHOWN TO
RIGHT, TAKE CARE NOT TO SPLIT
UPRIGHT TIMBER



4 REPEAT FOR THE REMAINING RM TIMBERS USING 120MM SCREWS INTO THE KING POST AND 180 SCREWS INTO THE UPRIGHT TIMBERS




INSTALLATION INSTRUCTIONS

5


SCREW RA - ROOF ASSEMBLIES TO RM TIMBERS

USING 6 X M8X80MM WOOD SCREWS PER SIDE, ENSURE ROOF IS POSITIONED AS SHOWN






6

REPEAT FOR THE REMAINING RA - ROOF ASSEMBLIES



INSTALLATION INSTRUCTIONS

7 SCREW TRIM TIMBERS TO THE MAIN ROOF SUPPORTS (RM TIMBERS) USING 4 X M8X80MM WOOD SCREWS FOR EACH SECTION





NOTES:

RTA / B TIMBERS ARE TO BE POSITIONED ALTERNATELY TO ENSURE THE TIMBERS DO NOT CLASH - SEE ABOVE FIG 1

ENSURE OVERHANG IS AS SHOWN ABOVE - FIG 2

8 ATTACH THE RT1 - ROOF CAP USING 4 X M8X80MM WOOD SCREWS





INSTALLATION INSTRUCTIONS

9

ATTACH ROOF BRACES

USING 4 X M8X80MM WOOD SCREWS (2 EITHER END) , ENSURE TIMBERS ARE PRE-DRILLED AND COUNTERSUNK



NOTES:

COMPOUND CUT FACE IS POSITIONED AGAINST THE UPRIGHT TIMBER

10

INSTALLATION COMPLETE

PLEASE CHECK ALL SCREWS COUNTERSUNK / NEAT SAND ANY TIMBERS AS REQUIRED

