



OS119 - OCTAVIA CANOPY (6M)

Installation Instructions

**creative
play**



PARTS REQUIRED




UPRIGHT TIMBERS



x452

97.M8X80CSK



x34


97.M8X120CSK



x18

97.M8X180CSK

PARTS REQUIRED




ROOF TRIM / KING 'POST'

RT

INCLUDES

RT1 - QTYx2
 RT2 - QTY x1
 RT3a - QTY x4
 RT3b - QTY x4
 RT3c - QTY x4



ROOF ASSEMBLIES

RA-L & RA-R

INCLUDES

RA-L - QTYx8
 RA-R - QTY x8




ROOF SUPPORTS ADDITIONAL

RBA

INCLUDES

RBA-u - QTY x 1 (SET)
 RBA-l - QTY x 1 (SET)



ROOF SUPPORTS

RS - QTY x 8

ROOF BRACES


RB

INCLUDES


RB-R QTY x 8 (RIGHT)
 RB-L QTY x 8 (LEFT)
 RB-T QTY x 8

FOUNDATION DETAILS

NOTES:
POST HOLES 400MM x 400MM




ENTRANCE



INSTALLATION INSTRUCTIONS

1 INSTALL THE UMT TIMBERS ACCORDING TO GROUND PLAN





2 ATTACH THE RS ROOF TIMBERS USING 2 X M8X80MM WOOD SCREW EITHER END, ENSURE TIMBERS ARE POSITIONED AS SHOWN

NOTES:


ENSURE TIMBERS ARE PRE-DRILLED AND
COUNTERSUNK

TIMBERS ARE POSITIONED LEVEL WITH THE TOP
OF THE UPRIGHT TIMBER






INSTALLATION INSTRUCTIONS



3 ATTACH RM TIMBERS TO KING POST (RT2) AND SCREW TO UPRIGHTS USING 2 X M8X120MM & 2 X M8X180MM WOOD SCREWS



NOTES:
ENSURE SCREWS ARE AS SHOWN TO
RIGHT, TAKE CARE NOT TO SPLIT
UPRIGHT TIMBER



4 REPEAT FOR THE REMAINING RM TIMBERS USING 120MM SCREWS INTO THE KING POST AND 180 SCREWS INTO THE UPRIGHT TIMBERS




INSTALLATION INSTRUCTIONS

5

SCREW THE RBA-U ROOF SUPPORTS TO THE RM TIMBERS


USING - 97.M8X120CSK - QUANTITY X 10



6

SCREW THE RBA-L ROOF SUPPORTS TO THE RM TIMBERS



USING - 97.M8X120CSK - QUANTITY X 8 / 97.M8X180CSK - QUANTITY X 2





INSTALLATION INSTRUCTIONS

7 ENSURE ALL TIMBERS ARE SCREWED INTO THE UPRIGHTS AND TOGETHER
USING - BOTH 120 & 180 SCREWS

NOTES:
USE 180 SCREWS TO SCREW
THROUGH THE LOWER & UPPER ROOF
BRACE SUPPORTS



8 ATTACH THE RA-L / RA-R ASSEMBLIES TO THE RM TIMBERS
USING - 97.M8X80CSK - QUANTITY X 8 (INTO EACH RM TIMBER EITHER SIDE)





INSTALLATION INSTRUCTIONS

9

SECURE THE 2 SECTIONS OF ROOF (L - R) TOGETHER


USING - 97.M8X80CSK - QUANTITY X 12 MIDDLE SECTION



10

REPEAT FOR THE REMAINING ROOF ASSEMBLIES

USING - 97.M8X80CSK - QUANTITY X 36 PER ROOF PANEL





INSTALLATION INSTRUCTIONS

11

ATTACH THE ROOF TRIM TIMBERS



USING - 97.M8X80CSK



12

REPEAT FOR THE REMAINING ROOF ASSEMBLIES

USING - 97.M8X80CSK - QUANTITY X 6 TIMBER



NOTES:


RT3b HAS A 'ANGLE CUT TOP'

INSTALLATION INSTRUCTIONS



13

ATTACH THE ROOF TRIM TIMBERS RT3c

USING - 97.M8X80CSK - QUANTITY X 6 TIMBER (4 FOR THE ROOF CAP)





RT1



14

ATTACH ROOF BRACES - LEFT / RIGHT

USING - 97.M8X80CSK - QUANTITY X 4 PER TIMBER




NOTES:

COMPOUND CUT FACE IS POSITIONED AGAINST THE UPRIGHT TIMBER

INSTALLATION INSTRUCTIONS

15 FURTHER SUPPORT THE ROOF USING RB-T TIMBERS

USING - 97.M8X80CSK - QUANTITY X 4 PER 'WEDGE'



NOTES:

RB-T TIMBER BLOCKS SECURES /
SUPPORT THE ADJOINING ROOF
ASSEMBLIES

16 INSTALLATION COMPLETE

PLEASE CHECK ALL SCREWS COUNTERSUNK / NEAT SAND ANY TIMBERS AS REQUIRED

