




PARTS required




PARTS required




TOOLS required


















Å

Installation Instructions




Installation Instructions




Attach the HANDLE

Using 2 x FM80 WOOD SCREWS / 2 x M8 COVERED ENDS







l

Installation Instructions

6 *Repeat STEPS 4 - 5 for the OPPOSITE END*

Using 5 x FM80 WOOD SCREWS / 2 x M8 COVERED ENDS

