

# **S116 - TRIPLE SWING**


## ***Installation Instructions***

**creative  
play**



# PARTS REQUIRED

---




X1

**DOUBLE SUPPORT BEAM**




X12

**M12 NYLOCS**



X1

**SINGLE SUPPORT BEAM**



X12

**M12 END CAP**



X4

**M8X80 WOODSCREWS**



X8

**M12X160 BOLT**



X4

**M12X260 BOLT**


# PARTS REQUIRED

---



X1

**CRADLE SEAT INC CHAINS**




X1

**MIRAGE INC CHAINS**




X1

**FLAT SEAT INC CHAINS**



X2

**PLAYTEC COVER**



X8



**S1 TIMBERS**




X12


**M8 NUT CAP**

# FOUNDATION DETAILS



# SURFACING DETAILS

-  = **SYNTHETIC**
-  = **LOOSE FILL**
-  = **AREA REQUIRED**




# INSTALLATION INSTRUCTIONS

**1**

**ATTACH PLAYTEC COVER AND S1 TIMBERS TO ONE END OF EACH BEAM**


USING M12X160 BOLTS [X8], M12 NYLOGS [X8] AND END CAPS [X8]



**2**

**ATTACH PLAYTEC COVER TO TIMBERS S1**

USING M8X80 WOODSCREWS [X4]




# INSTALLATION INSTRUCTIONS

**3**

**SECURE BOTH BEAMS AND MIDDLE TIMBERS TOGETHER**


USING M12X260 BOLTS [X4], M12 NYLOGS [X4] AND END CAPS [X4]



**4**

**INSTALL THE ASSEMBLY**

FOLLOW FOUNDATION DETAILS




# INSTALLATION INSTRUCTIONS

---

**5**

## ATTACH SEATS TO BEAM

FOLLOW DIMENSION DETAILS ON NEXT PAGE



# ***ADDITIONAL DIMENSIONS***

