


# **S118-R - DOUBLE SWING & BASKET ROUND**

## ***Installation Instructions***


**creative  
play**



# PARTS REQUIRED



**TOP BEAM - DOUBLE SWING**



**TOP BEAM - BASKET SWING**



**UPRIGHTS S101R1**




**FLAT SEAT (INC CHAIN)**




**CRADLE SEAT (INC CHAIN)**




**BASET SEAT INC CHAINS**



**QUICKLINK**




**300MM CHAIN**



**BLACK M8 NUT CUP**


# PARTS REQUIRED

---



x12

**END CAPS**




x12

**M12 NYLOC NUT**



x12



**M12 x 320 SQUARE CUP BOLT**



x16


**BLACK M8 NUT CUP**

# FOUNDATION DETAILS



# ***SURFACING DETAILS***

- - - - - = MINIMUM SPACE***
- = SURFACE AREA***
- = SYNTHETIC***




# INSTALLATION INSTRUCTIONS

**1**

## BUILD THE DOUBLE SWING FRAME

USING M12X310 X 6 / NYLOGS X 6 / END CAPS X 6

■ OUTSIDE TIMBERS




**2**

## BUILD THE BASKET SWING FRAME

USING M12X310 X 6 / NYLOGS X 6 / END CAPS X 6


■ OUTSIDE TIMBERS



# INSTALLATION INSTRUCTIONS


**3**

**INSTALL ASSEMBLY**  
**FOLLOW FOUNDATION DETAILS**



**4**

**INSTALL SEATS ACCORDING TO HEIGHT SPECIFIED IN ADDITIONAL DIMENSIONS**  
**USING M8 NUT CUP X16 . ADDITIONAL DIMENSIONS FOR SEAT HEIGHT**



# ADDITIONAL DIMENSIONS

## SEAT HEIGHT BELOW

