



S119-R - QUAD SWING ROUND

Installation Instructions

**creative
play**



PARTS REQUIRED




x2

TOP BEAM - DOUBLE SWING



x8

UPRIGHTS S101R1



x16

BLACK M8 NUT CUP




x2

FLAT SEAT (INC CHAIN)




x1

CRADLE SEAT (INC CHAIN)




x1

BASKET SWING (INC CHAIN)



x12

END CAPS



x12



M12 NYLOC NUT



x12

M12 x 320 SQUARE CUP BOLT

FOUNDATION DETAILS




SURFACING DETAILS

- - - - - = MINIMUM SPACE

————— = SURFACE AREA


■ = SYNTHETIC



INSTALLATION INSTRUCTIONS


1 BUILD THE DOUBLE SWING FRAME USING M12X310 X 6 / NYLOGS X 6 / END CAPS X 6

■ OUTSIDE TIMBERS



2 BUILD THE 2ND DOUBLE SWING FRAME USING M12X310 X 6 / NYLOGS X 6 / END CAPS X 6


■ OUTSIDE TIMBERS



INSTALLATION INSTRUCTIONS


3

INSTALL ASSEMBLY
FOLLOW FOUNDATION DETAILS



4

INSTALL SEATS ACCORDING TO HEIGHT SPECIFIED IN ADDITIONAL DIMENSIONS
USING M8 NUT CUP X16 . ADDITIONAL DIMENSIONS FOR SEAT HEIGHT



ADDITIONAL DIMENSIONS

SEAT HEIGHT BELOW

