



AT7 - ADVENTURE TRAIL 7

Installation Instructions

**creative
play**




PARTS REQUIRED



UPRIGHT TIMBERS

*PLEASE NOTE ALL H TIMBERS ARE PRE-ASSEMBLED WITH PLAYTEC L's AND/OR EKO GRIP (AS SHOWN ABOVE)

| CODE | TIMBER | SIZE | QTY | END | ADDITIONAL INFORMATION |
|---------|--------|------|-----|---------|------------------------|
| AT - U1 | 90x90 | 1800 | 4 | END CAP | UPRIGHT TIMBERS |
| AT - U2 | 90x90 | 2715 | 1 | END CAP | UPRIGHT TIMBERS |
| AT - U3 | 90x90 | 2715 | 1 | END CAP | UPRIGHT TIMBERS |
| AT - U4 | 90x90 | 3000 | 1 | | UPRIGHT TIMBERS |
| AT - U5 | 90x90 | 3000 | 1 | | UPRIGHT TIMBERS |
| AT - U6 | 90x90 | 2335 | 1 | END CAP | UPRIGHT TIMBERS |
| AT - U8 | 90x90 | 1800 | 4 | END CAP | UPRIGHT TIMBERS |




HORIZONTAL TIMBERS

**PLEASE NOTE ALL H TIMBERS ARE PRE-ASSEMBLED WITH PLAYTEC L'S AND/OR EKO GRIP (AS SHOWN ABOVE)*


| CODE | SIZE | QTY | START | END | ADDITIONAL INFORMATION |
|----------------|-------------|------------|--------------------|--------------------|------------------------------------------|
| <i>AT - H1</i> | <i>900</i> | <i>1</i> | <i>END CAP</i> | <i>END CAP</i> | <i>HORIZONTAL TIMBER (EKO GRIP SLAT)</i> |
| <i>AT - H2</i> | <i>2100</i> | <i>2</i> | <i>PLAYTEC L'S</i> | <i>PLAYTEC L'S</i> | <i>HORIZONTAL TIMBER</i> |
| <i>AT - H3</i> | <i>900</i> | <i>1</i> | <i>END CAP</i> | <i>END CAP</i> | <i>HORIZONTAL TIMBER (EKO GRIP SLAT)</i> |
| <i>AT - H4</i> | <i>2010</i> | <i>1</i> | <i>END CAP</i> | <i>END CAP</i> | <i>HORIZONTAL TIMBER (EKO GRIP SLAT)</i> |
| <i>AT - H5</i> | <i>2100</i> | <i>1</i> | <i>PLAYTEC L'S</i> | <i>PLAYTEC L'S</i> | <i>HORIZONTAL TIMBER</i> |
| <i>AT - H6</i> | <i>2160</i> | <i>1</i> | <i>END CAP</i> | <i>END CAP</i> | <i>HORIZONTAL TIMBER (EKO GRIP SLAT)</i> |
| <i>AT - H7</i> | <i>2100</i> | <i>1</i> | <i>END CAP</i> | <i>END CAP</i> | <i>HORIZONTAL TIMBER (EKO GRIP SLAT)</i> |

PARTS REQUIRED




x2

CLIMBING PANELS (UPPER)



x2

CLIMBING PANELS (LOWER)



x1

ROPE BRIDGE



x3

SWINGING ROPES



x1

ROPE WALK CHAIN X 1920MM



x1

TRAVERSE ROPE




x12

274.M12X200



x27


656.M12



x27


102003-01 - M12

PARTS REQUIRED



x47

97.M8X80CSK




x2

M12 SOCKET NUT (50MM)




x1

274.M12X220



x1

274.M12X180



**CONSISTS OF
SHACKLE / BOLT / NYLOC / CAP**


x2

349.742.D-SHACKLE 'SET'



x2


M12 EYEBOLTS




x1

LOG WALK (PRE-ASSEMBLED)

FOUNDATION DETAILS




SURFACING DETAILS




INSTALLATION INSTRUCTIONS

1 POSITION THE UPRIGHT TIMBERS FOLLOWING FOUNDATION DETAILS




2 ATTACH TIMBER H1 USING 274.M12X200 / 656.M12 / 102003-01, SECURE EKO GRIP WITH M8X80MM WOOD SCREWS




INSTALLATION INSTRUCTIONS


3 ATTACH H2 TIMBERS USING PLAYTEC L'S
USING M8X80MM WOOD SCREWS, TAKE CARE THAT SCREWS DO NOT 'CROSS'



4 ATTACH TIMBER H3
USING 274.M12X200 / 656.M12 / 102003-01



NOTES:
H3 EKO GRIP SLAT WILL NOT BE ATTACHED UNTIL STEP 7





INSTALLATION INSTRUCTIONS

5

ATTACH ROPE BRIDGE


USING 656.M12 / 102003-01




6

ATTACH TIMBER H4 AND LOWER PLAYTEC CLIMBING PANEL SHOWN

USING 274.M12X180 & 220 / 656.M12 / 102003-01 AND M8X80MM WOOD SCREWS




180 BOLT



NOTES:

ATTACH PANEL ON OPPOSITE FACE TO BEAM


ONE LOWER PLAYTEC PANEL HAS HOLE DRILLED FOR BOLT (SEE CNC)




220 BOLT

INSTALLATION INSTRUCTIONS


7 ATTACH H3 EKO GRIP SLAT USING 8X80MM WOOD SCREWS TO COVER COUNTERSUNK BOLT



8 ATTACH REMAINING 3 PLAYTEC CLIMBING PANELS USING 8X80MM WOOD SCREWS



NOTES:
ENSURE SECOND SET OF PANELS
ARE ON OPPOSITE FACE TO FIRST




NOTES:
THIS PANEL IS ALREADY ATTACHED AS
PER STEP 6

INSTALLATION INSTRUCTIONS

9

ATTACH TIMBER H5 USING PLAYTEC L'S


USING 8X80MM WOOD SCREWS



10

ATTACH SWINGING ROPES TO TIMBER H5

USING 656.M12 / 102003-01




INSTALLATION INSTRUCTIONS

11

ATTACH SWINGING ROPE CHAIN


USING M12 X 50MM SOCKET NUT, D - SHACKLE AND EYEBOLT SHOULD BE PRE-ATTACHED TO CHAIN



12

ATTACH TIMBER H6

USING 274.M12X200 / 656.M12 / 102003-01





INSTALLATION INSTRUCTIONS

13

ATTACH TRAVERSE ROPE ABOVE TIMBER H6



USING 656.M12 / 102003-01



14

ATTACH TIMBER H7

USING 274.M12X200 / 656.M12 / 102003-01




INSTALLATION INSTRUCTIONS



15

ATTACH LOG WALK TO AT8 UPRIGHTS

USING .M12X200 [X4]/ NYLOCS M12 X4/ X4 ENDCAPS



ADDITIONAL DIMENSIONS



*** MAX FALL HEIGHT**